



Tel: 604.521.6444  
 Fax: 604.521.3143  
 Toll Free Tel: 1.800.668.4996

## PRESS BRAKE PUNCHING CHART

FORCE IN TONS																			
Gauge	28	26	24	22	20	18	16	14	12	11	10	5/32"	3/16"	1/4"	3/8"	1/2"	5/8"	3/4"	1"
Thickness (in)	0.015	0.018	0.024	0.030	0.036	0.048	0.060	0.075	0.105	0.120	0.135	0.157	0.188	0.250	0.375	0.500	0.625	0.750	1.000
HOLE DIAMETER																			
1/8" 0.125"	0.24	0.24	0.24	0.36	0.48	0.72	0.84	1.20	1.44	1.56									
3/16" 0.1875"	0.24	0.36	0.48	0.48	0.60	0.84	1.08	1.32	1.80	2.16	2.40	2.76	3.36						
1/4" 0.250"	0.36	0.48	0.60	0.72	0.84	1.08	1.44	1.80	2.52	2.88	3.12	3.72	4.44	5.88					
5/16" 0.3175	0.48	0.48	0.72	0.84	1.08	1.44	1.80	2.16	3.12	3.48	3.96	4.56	5.52	7.32					
3/8" 0.375	0.48	0.60	0.84	1.08	1.32	1.68	2.16	2.64	3.72	4.20	4.80	5.52	6.60	8.88	13.32				
7/16" 0.5625	0.60	0.72	0.96	1.20	1.44	1.92	2.52	3.12	4.32	4.92	5.52	6.48	7.68	10.32	15.36				
1/2" 0.500	0.72	0.84	1.08	1.44	1.68	2.28	2.76	3.48	4.92	5.64	6.36	7.32	8.88	11.76	17.76	23.64			
9/16" 0.4375	0.84	0.96	1.32	1.56	1.92	2.52	3.12	3.96	5.52	6.12	7.08	8.28	9.96	13.32	19.80	26.40			
5/8" 0.625	0.84	1.08	1.44	1.80	2.16	2.88	3.48	4.44	6.12	7.08	7.92	9.24	11.04	14.76	22.20	29.52	36.96		
11/16" 0.6875	0.96	1.20	1.56	1.92	2.28	3.12	3.84	4.80	6.84	7.44	8.76	10.08	12.12	16.20	24.24	31.80	40.44		
3/4" 0.750	1.08	1.22	1.68	2.16	2.52	3.36	4.20	5.28	7.44	8.52	9.48	11.04	13.20	17.64	26.52	35.40	44.28	53.16	
13/16" 0.8125	1.20	1.32	1.80	2.28	2.76	3.72	4.56	5.76	8.04	9.12	10.32	12.00	14.40	19.20	28.56	38.16	47.88	57.24	
7/8" 0.875	1.32	1.44	1.92	2.52	3.00	3.96	4.92	6.12	8.64	9.96	11.04	12.84	15.48	20.64	30.96	41.28	51.60	62.04	
15/16" 0.9375	1.44	1.56	2.16	2.64	3.12	4.20	5.28	6.60	9.24	10.56	11.88	13.80	16.56	22.08	33.00	44.16	55.20	66.24	
1" 1.000	1.56	1.68	2.88	2.88	3.36	4.56	5.64	7.08	9.84	11.28	12.72	14.76	17.76	23.64	35.40	47.28	59.04	70.80	72.00

**Tons required per hole to punch mild steel having max 72,000 PSI tensile strength and max 40,000 PSI yield strength.**

For smooth trouble-free operation, the punching tonnage should not exceed two-thirds of the rated capacity of the press. In multiple punching setups, the punches should be stepped by setting punches at different levels.

If the punches are on two levels, the punching tonnage required may be divided by two.

If they are set on the three levels, the tonnage may be divided by three.

Website: [www.punchtools.com](http://www.punchtools.com) • Email: [sales@punchtools.com](mailto:sales@punchtools.com)